SMART*Brief*

TECHNICAL BULLETIN

DATE:	18 April 2008	No:	SB-08041801
TO:	Contractors & Distributors	Page	1 of 1
FROM:	Metro Technical Services Division		
SUBJECT:	**METRO ROMAN PANELS INSTALLED BATTEN-LESS**		

Metro Roman Tile Installed BATTEN-LESS
Based on the large number of Roman Tile BATTEN-LESS applications installed in Florida and other parts of the country with screws. Metro now recommends that, at a minimum, screws be used on the nose of the Roman tiles when installing them in a Batten-Less configuration.

When installing Metro Roman panels on a solid deck using the Batten-Less install method the panels are to be fastened to the roof deck with fasteners as noted below.

Roman Panel "BACK-FLANGE"
Four (4) #10 X 2" inch Long HH CS Screws, across the back of each panel (for HVHZ areas refer to Metro approvals for correct number of fasteners). As an alternate four (4) .131" inch X 2-3/8" inch Ring Shank Nails are acceptable at this location.

Roman Panel "FRONT DOWN-TURN NOSE"
Four (4) #10 X 2-1/2" inch Long HH CS Screws, across the Nose of each panel (for HVHZ areas refer to Metro approvals for correct number of fasteners).

Metro Roof Products

3093 'A' Industry Street
Oceanside CA 92054
Tel: (760) 435-9842
Fax: (760) 435-1162

www.smartroofs.com

Metro Roof Products SMARTBrief Technical Bulletins are for use by all Metro Roof Products customers. Each SMARTBrief is coded with a reference number and can be used to support various trade practices that are acceptable to, and have met Metro Roof Products quality standards in effect at the time. Metro Roof Products reserves the right to amend or update these SMARTBrief Technical Bulletins at any time.
C:\Documents and Settings\Peter\My Documents\TECHNICAL\SMART Briefs\08041801-Roman BATTEN-LESS Fasteners.doc